



Note: Other wiring setups are possible; see the User and Installation Guide for details.

RECEIVER 7.5/10/12

SATELLITE DISH
1500W 222V 50/60Hz

TELEVISION

Right AUDIO Input
Left AUDIO Input
VIDEO Input
RF Input

Inside Building
Outside Building

Single Output LNB's
on Dish 1 and Dish 2

**Multi-Dish Switch
Model SW21**
(Install outside building)

Microcrystal
SW-21

RG-6 Coaxial
Cable

NOTE: Ground each satellite dish, coaxial cable, and switch in accordance with the *National Electrical Code (NEC)* and all electrical codes. Put drip loops in the cables to allow moisture to drip off before running into equipment or building. Cable lengths should not exceed 100 ft.

Drip Loop

Cable Clip